


DE-SCALING REMOVER LIQUID



Technical Description:

Anticorrosive Descaling liquid used to remove scale and rust in heating systems, cooling circuits with pipes in copper, iron and steel.

Dissolves iron oxides at ambient temperature.

How to use:

Let the product circulate inside the plant, diluted in water at 10-30 % (1-3 liters of the product in 10 liters of water), starting with the lower concentration.

When the color changes, from red to yellow-orange, add some *Remover Liquid* until there is no more effervescence in the red acid solution.

Once the descaling treatment has ended, wash the installation with a solution of *Neutralizer* at 2-3 % concentration, and rinse with running water afterwards.

Risk Classification:

R 36 / 38: Irritating to eyes and skin.

Warnings

S 2: Keep out of the reach of children

S 26: In case of contact with eyes, immediately wash with plenty of water and ask for a doctor

S 28: In case of contact with skin, immediately wash with plenty of water and sodium bicarbonate.



Xi Irritant

